# primacare seating | product specification

High Traffic Bariatric Seating Models: GC3637, GC3638, GC3639, GC3640, GC3656, GC3679

# Guest Chair Dimensions (Model GC3637)

Overall Depth	27 in / 686 mm	
Overall Width	35 in / 889 mm	
Overall Height	33 in / 838 mm	
Seat Depth	17.5 in / 445 mm	
Seat Width	30 in / 762 mm	
Seat Height	18 in / 457 mm	
Back Height - From	15 in / 381 mm	
Armrest Clearance	30 in / 762 mm	
Arm Height - From Seat		8.5 in / 216 mm
Product Weight	GC3637	66 lb / 30 kg
	GC3637CA	76 lb / 34.5 kg
Shipping Cube	26.5 ft <sup>3</sup> / 0.75 m <sup>3</sup>	

#### Patient Chair Dimensions (Models: GC3638, GC3639, GC3656)

Overall Depth		27 in / 686 mm
Overall Width		35 in / 889 mm
Overall Height	GC3638 GC3639, GC3656	36.5 in / 927 mm 48.5 in / 1232 mm
Seat Depth		17.5 in / 445 mm
Seat Width		30 in / 762 mm
Seat Height		18 in / 457 mm
Back Height - From Seat	GC3638 GC3639, GC3656	18 in / 457 mm 30 in / 762 mm
Armrest Clearance		30 in / 762 mm
Arm Height - From Seat		8.5 in / 216 mm
Product Weight	GC3638 GC3638CA GC3639, GC3656 GC3639CA, GC3656CA	82 lb / 37.3 kg 92 lb / 41.8 kg 67 lb / 30.5 kg 96 lb / 43.6 kg
Shipping Cube	GC3638 GC3639, GC3656	30.5 ft <sup>3</sup> / 0.86 m <sup>3</sup> 33 ft <sup>3</sup> / 0.93 m <sup>3</sup>

# Lounge Chair Dimensions (Models: GC3640, GC3679)

Overall Depth	GC3640	32 in / 813 mm
	GC3679	29 in / 737 mm
Overall Width	GC3640	40 in / 1016 mm
	GC3679	42 in / 1067 mm
Overall Height	GC3640, GC3679	33 in / 838 mm
	GC3679HB	36 in / 914 mm
Seat Depth		20 in / 508 mm
Seat Width		36 in / 914 mm
Seat Height		17.25 in / 438 mm
Back Height -	GC3640, GC3679	16 in / 406 mm
From Seat	GC3679HB	19 in / 483 mm
Armrest Clearance		36 in / 914 mm
Arm Height - From Seat		8 in / 203 mm
Product Weight	GC3640	97 lb / 44.1 kg
	GC3640CA	107 lb / 48.6 kg
	GC3679	95 lb / 43.2 kg
	GC3679HB	109 lb / 49.5 kg
Shipping Cube	GC3640	49.5 ft³ / 1.40 m³
	GC3679	37.75 ft <sup>3</sup> / 1.07 m <sup>3</sup>

Contact sales representative for more information.

# Features

- Wall saver leg design prevents chair back from contact with wall
- Integrated lumbar support
- Easy grip forward extending armcaps
- Standard Self-Skinned Urethane (SSU) armcaps
- Standard with metal mesh seat deck
- Complementing tables are available
- Shipped fully assembled

# Options

- Under arm space is open, as standard, but closed arms are available for all models in matching upholstery (CA models)
- SSU armcaps are available in several colors
- Optional wood armcaps are available in any standard Globalcare wood finish



# **primacare seating** | product specification

#### **COM Yardage**

Yardage is based on unmatched materials with widths of 54 inches for seating

MODEL GC3640

• Full Unit: 3.25 yards

• Full Unit: 3.50 yards

• Full Unit: 6.50 yards

• Back: 2.00 yards

• Seat: 1.25 yards

• Back: 2.50 yards

• Seat: 1.00 yards

• Back: 5.00 yards

• Seat: 1.50 yards

MODEL GC3679

MODEL GC3656

#### MODEL GC3637

- Full Unit: 2.50 yards
- Back: 1.50 yards
- Seat: 1.00 yards MODEL GC3638
- Full Unit: 2.75 yards
- Back: 1.85 yards
- Seat: 0.90 yards

# MODEL GC3639

- Full Unit: 3.75 yards
- Back: 2.75 yards
- Seat: 1.00 yards

# MODEL GC3639

- Full Unit: 3.75 yards
- Back: 2.75 yards
- Seat: 1.00 yards

MODELS: GC3637CA, GC3638CA, GC3656CA, GC3639CA (closed arms)

- Add 1.00 yard to the unit yardage
- MODEL GC3640CA (closed arms)
- Add 2.50 yards to unit yardage
- MODEL GC3679HB (high back)
- Add 0.25 yards to back and unit yardage

#### Infection Control

- No Velcro on seat
- · Seam sealing option
- Zipper sealing option
- Waterfall cleanout between seat and back cushions
- Metal mesh seat deck. For mental health applications, seat deck can be covered with a solid moisture resistant surface with tamperproof fasteners
- SSU armcaps are cleanable and non-porous
- For proper cleaning and disinfecting practices, the textile selection needs to be identified. It is vital that following any chemical application a clear water wipe down occur to avoid chemical build up that will lead to deterioration of the textile. Contact Global should information on using a specific disinfectant be required

#### On Site Repair and Replacement

- All components are field replaceable including seat, back, armcaps and arm frames
- Arm frame are interchangeable allowing for on-site conversion from steel to wood and open arm frames to/from closed arm frames
- Armcaps are interchangeable allowing for on-site conversion from SSU armcaps to wood armcaps

MODELS: GC3637CA, GC3638CA, GC3656CA, GC3639CA

• Upholstered arm panels are replaceable

#### Construction (Overall Frame)

- Metal frame with die-cast zinc connectors and metal-to-metal fasteners
- Arm frames use 14 gauge rectangular tube construction

#### Construction (Armcaps)

- SSU armcaps
- Armcaps are molded around a formed steel insert ensuring a metal to metal connection

### Construction (Seat)

- 14 gauge rectangular tube seat frame
- Welded wire mesh seat deck

#### Construction (Back)

 ¾ in (19 mm) thick molded veneer back, mechanically fastened to back uprights using metal-to-metal connections

# Construction (Glides)

• Non-marking, black, polypropylene/polyethylene glides

# Upholstery

- Zippered seat cushion
- Seat cushion hooks to underside of seat deck and back rail using proprietary C-clip fastener
- Back cushion hooks to underside of back using proprietary C-clip fastener

#### Foam

- Seat and back cushions have 3.5 in (89 mm) thick molded urethane foam
- Back foam density: 1.9 lb, ILD: 22
- Seat cushion is Ultracell foam. Density: 2.6, ILD: 35

#### Weight Capacity

Bariatric seating has an active weight capacity of 500 lb.



# primacare seating | product specification

# Warranty

Lifetime warranty on all components except the following:

- 5 year warranty on foam and textiles
- Warranty applies only to single shift, standard commercial usage (8 hours/day, 5 days/week)

### Fire Rating

All textiles and foam is tested and certified, meeting California Technical Bulletin 117 (CAL 117-2013) standards.

#### **Environmental**

View <u>Environmental Data Sheets</u> online. All foam is produced without using any ozone depleting chloro-flouro chemicals.

#### Awards/Certifications

- Meets or exceeds all applicable BIFMA standards for safety and durability
- Manufactured in ISO 9001 and 14001 certified facilities

Please visit globalfurniture group.com for additional product information including environmental certifications.

